



☐ RM-7 FUTURA ☐ RM-17 FUTURA II

Regadera Manual con Desviador
Hand Shower Head with Diverter

☐ RM7-6 FUTURA

Regadera Manual con Desviador, 6,0 LPM
Hand Shower Head with Diverter, 1,58 GPM



garantía de calidad

Agradecemos su elección por los productos HELVEEX. Estamos seguros de que su confiabilidad por el producto excederá sus más altas expectativas, cuya funcionalidad, estética, durabilidad, respaldo integral y alta calidad le otorgarán plena satisfacción por años, reflejando el compromiso con la calidad, innovación y el medio ambiente que forman parte de Helvex.

Thank you for choosing HELVEEX products. We are confident that the product reliably will exceed your highest expectations. This product's functionality, aesthetics, durability, quality and support will grant you full satisfaction for years, thus reflecting Helvex's commitment to quality, innovation and the environment.

Esta Guía de Instalación Aplica al Producto en Cualquier Acabado.
This Installation Guide Applies to the Product in any Finishing.


Asesoría y Servicio Técnico
Technical Support and Service
servicio.tecnico@helvex.com.mx
(52) 55 53 33 94 31

Refacciones Originales
Original Spare Parts
refacciones@helvex.com.mx
www.refaccioneshelvex.com.mx
(52) 55 53 33 94 21
(52) 55 53 33 94 00
Ext. 5913, 5068 y 4815
whatsapp 55 8071 7454

Herramientas y Materiales
Requeridos (no incluido)



Required Tools and
Materials (not included)



Información



Information



Sin fuga
No leakage



Reensamblar
Reassemble



Revisar
Review

Acabados: Finishes:

Cromo

Polished Chrome





Requerimientos de Instalación Installation Requirements

Para el correcto funcionamiento de estos productos, se recomiendan las siguientes presiones:

For the correct functioning of these products, the recommended water pressures are:

Modelo Model	Mínima Minimum			Máxima Maximum		
	kg/cm ²	PSI	kPa	kg/cm ²	PSI	kPa
RM-7 RM7-6 RM-17	0,2	2,84	19,61	6,0	85,3	588,3

Antes de Instalar Before of Installation

- Para disminuir el riesgo de lesiones o daños a la propiedad, lea todas las instrucciones antes de instalar el producto.
- Utilice gafas de seguridad.
- En obras de construcción, instalación, modificación, ampliación y reparación deben cumplir con el reglamento de construcción y obras de su localidad.
- El producto ilustrado puede sufrir cambios de aspecto como resultado de la mejora continua a la que está sujeto.

- To reduce the risk of injury or property damage, please read all instructions before installing the product.
- Wear safety glasses.
- For any construction, installation, alteration, extension or repair, comply with your local building codes.
- The product's illustration may vary in appearance to the actual product as a result of our continuous improvement process.

Problemas, Posibles Causas y Soluciones Troubleshooting

Problema	Causa	Solución
Hay fuga en las conexiones.	No se colocó cinta teflón en las conexiones roscadas.	Colocar cinta teflón en las conexiones roscadas.
	No se colocaron los empaques.	Coloque los empaques y apretar firmemente las conexiones roscadas.
Disminución del chorro de agua.	El tapete anticálcero está obstruido. (RM-5 y RM-17)	Realice mantenimiento.
	La presión en la instalación no es la adecuada.	Verifique que la presión mínima de operación sea la correcta.
No se realiza el desvío del agua.	El o'ring o el casquillo están dañados.	Reemplace las piezas dañadas.

Problem	Cause	Solution
There are leaks in the connections.	Did not place plumber's tape on the threads.	Place plumber's tape on the threaded connections.
	The gaskets were not placed.	Place the gaskets and tighten the threaded connections firmly.
Water flow decreased.	Anti-limescale plate is clogged. (RM-5 and RM-17)	Perform maintenance.
	The operating pressure is not adequate.	Verify that the minimum operating pressure is correct.
Water diversion is not performed.	The o'ring or the bushing are damaged.	Replace damaged parts.

Recomendaciones de Limpieza Cleaning Recommendations

Es muy importante seguir las siguientes instrucciones para conservar los acabados de los productos HELVEX, con brillo y en perfecto estado:

1. Utilice únicamente agua y un paño limpio.
2. No utilice fibras, polvos, abrasivos, ni productos químicos.
3. No utilice objetos punzo-cortantes para limpiar los acabados.
4. Se recomienda realizar la limpieza de su producto diariamente.

Visite nuestras páginas www.helvex.com.mx para México y www.helvex.com para el mercado Internacional

It is very important to follow the instructions below to preserve HELVEX products finishes, shiny and in perfect condition:

1. Use only water and a clean cloth.
2. Do not use fibers, powders, abrasives, or chemicals.
3. Do not use sharp objects to clean the finish.
4. It is recommended to clean your product daily.


Visit our pages www.helvex.com.mx for Mexico and www.helvex.com for the International market.




Componentes



Components



RM-17




RM-7, RM7-6

Aplica para los modelos: / Applies to models:
RM-5, RM-7 y RM-17

- | | | |
|----|---------------------|---------------------|
| 1 | Taquete | Anchor |
| 2 | Ancla | Wall Bracket |
| 3 | Tornillo | Screw |
| 4 | Ancla | Wall Bracket |
| 5 | Ancla/Soporte | Wall Bracket/Holder |
| 6 | Opresor | Set Screw |
| 7 | Regadera Manual | Hand Shower Head |
| 8 | Economizador | Flow Restrictor |
| 9 | Niple | Nipple |
| 10 | Empaque | Gasket |
| 11 | Chapetón | Escutcheon |
| 12 | Cuerpo de Regadera | Shower Body |
| 13 | Casquillo Desviador | Diverter Housing |
| 14 | Varilla Armada | Assembly Rod |
| 15 | Llave Allen | Allen Wrench |


Aplica para el modelo: / Applies to model:
RM7-6




- | | | |
|----|--------------------|--------------------------|
| 16 | Economizador 6 LPM | 1,58 GPM Flow Restrictor |
|----|--------------------|--------------------------|



Instalación

Installation





Mantenimiento

Maintenance

